

# AUTOMATIC WATCH WITH OR WITHOUT DATE

## WATCH WITHOUT DATE or WATCH WITH DATE, WITHOUT QUICKSET

The crown has 2 positions:

1. Normal position - wearing position

In this position the watch can be wound using the crown. If you always wear the watch or the watch is on a watchwinder, you don't need to wind it. If you haven't worn the watch for a while and the watch has stopped, please wind the watch a little before setting or wearing it. About 10 to 15 turns of the crown should be sufficient. When the crown is positioned against the case this ensures that the watch is water resistant. Please note that we do not guarantee the watch being waterproof or water resistant. Please make sure that when you handle the crown in any way the watch is in your hand, not on your wrist. This is because there is a possibility you bend or damage the crown tube and / or case of the watch, should you handle the crown when the watch is on your wrist.

2. Pulled out position - time (and date) setting

When the crown is pulled out, it can be used to set the time. The crown can be turned forwards and backwards. To set the date please keep moving the the crown forwards (clockwise) to the desired date.

## WATCH WITH DATE QUICKSET

The crown has 3 positions:

1. Normal position - wearing position

In this position the watch can be wound using the crown. If you always wear the watch or the watch is on a watchwinder, you don't need to wind it. If you haven't worn the watch for a while and the watch has stopped, please wind the watch a little before setting or wearing it. About 10 to 15 turns of the crown should be sufficient. When the crown is positioned against the case this ensures that the watch is water resistant. Please note that we do not guarantee the watch being waterproof or water resistant.

2. Pulled out once position - date setting

When the crown is in this position the crown can be turned upwards to change the date. When using the quickset function to change the date please make sure the time is first set to 6 o'clock. This is because around 12 o'clock the watch itself is mechanically changing the date. Should you try to change the date manually when the watch is using this function there is a chance you damage the mechanism. When the time is set at or around 6 o'clock this mechanism can not be damaged.

3. Pulled out twice position - time setting

When the crown is pulled out twice, it can be used to set the time. The crown can be turned forwards and backwards.